IMPORTANT NOTES:

a) It is recommended to keep your instruction manual in the vehicle to have the unit details and Securi-Lid contact numbers on hand.

b) Never force your key left or right in the barrel as it can break off in the key chamber.

c) Check that the key slot is in the unlocked position when closing the Securi-Lid to avoid the keys being locked inside the load area and to avoid the locking mechanism from getting jammed.

d) Keep the dust cover over the lock in the closed position to avoid dirt and dust from getting into the key chamber.

e) When releasing the door, ensure you hold onto the strap and allow the door to roll back in a controlled manner.

f) The roller door is spring loaded and damage to the roller door can be caused by it rolling back in an uncontrolled manner.

g) The Securi-Lid is not 100% waterproof or dustproof. The vehicle's tailgate area and panel gaps are susceptible to dust and water ingress.

h) The transporting of sand/dirt in the load bin with the door open or closed is not recommended (See Warranty Information).

i) It is recommended that the **Securi-Lid Cari-On Racks** are used to carry extra load to avoid damage and scratches on the roller shutter. It is important to check the load specifications before loading onto the Cari-On Racks.

j) Do not leave small objects on top of the roller door when opening as it may slip into the canister. This may cause the door to jam and become damaged.

k) When closing the Securi-Lid, make sure the strap is inside the load box to avoid it getting caught up outside the vehicle.

l) Unsuitable chemicals and cleaning detergents are not recommended for cleaning the unit. (See Maintenance and Cleaning).

m) Styling bars are for decorative purposes only and are not intended to provide safety or protection.

WARRANTY INFORMATION:

a) The obligation in terms of this warranty shall be limited to repairing or replacing any part or parts, which in the opinion of Securi-Lid, are defective in materials or workmanship under normal use and service during the **warranty period commencing from the original fitment date.**

b) The warranty does not apply if the unit has been subjected to negligence, damage, abuse, misuse, improper maintenance, or has been repaired or altered by someone other than Securi-Lid, it's authorised agents or approved fitment centres. Negligence includes, but is not limited to, driving the vehicle on dirt or gravel roads with the Securi-Lid in the partially or fully open position.

c) Warranty will be null and void, should the Securi-Lid be fitted by an unauthorised fitment centre as well as removal and refitment to the same or other vehicle.

d) Obligations extend to Cari-On Racks(12-month warranty from date of fitment) fitted to the Securi-Lid.

e) For refitted and /or modified styling bars, the relevant Securi-Lid bracket sets are to be used. A 12-month warranty is applicable on the material and the coating of bracket sets only, provided that said brackets are not damaged on or after fitment, with the applicable warranty obligations listed as above.
Securi-Lid, nor its Distribution Agents, do not warrant the workmanship and / or accept any liability in terms of the modification, preparation or treatment of any styling bar that is modified by a third party or fitment centre.

f) An annual chargeable service by an authorised fitment centre is required to maintain the validity of the 3-year warranty.

g) Any defect must be reported to the regional distributor (listed on the website of Securi-Lid, but in any event, no later than ten days after the defect arose.
The regional distributor will make arrangements for the unit to be inspected at the nearest Securi-Lid approved agent or fitment centre. If the inspection reveals that the unit is not defective or the warranty is excluded, you will be liable for the costs of the inspection.

SAFETY NOTES:

a) Do not drive with persons or animals under the roller shutter and do not allow persons or animals in the load bin when the roller shutter is closed.

b) Temperatures underneath the roller shutter can become very high when closed.

c) Servicing of the roller shutter should be done by an approved fitment centre.

d) Only operate the roller shutter using the pull strap in conjunction with the rubber grab handle on the locking rail. Avoid pinch points between the tailgate and locking rail (during closing) and canister lid and locking rail (during opening).

e) In environments subjected to snow and/or ice, sweep and/or de-ice the surface of the roller shutter door prior to operating.

OPERATING INSTRUCTIONS:

When operating, ensure the lock is in the unlocked position with the key removed.

UNLOCKING AND LOCKING:

- To unlock your Securi-Lid lift the dust cover and insert the key into the lock cylinder in the 8 o'clock position and rotate it 90 degrees to the 4 o'clock position.
- To lock the Securi-Lid lift the dust cover and insert the key into the lock cylinder in the 4 o'clock position and rotate it 90 degrees to the 8 o'clock position.

OPENING:

- Lift the release handle and let the door roll back gently while holding the raised rubber on the grab handle with one hand.
- Take hold of the strap attached to the locking rail and allow the roller door to retract in a controlled manner.

CLOSING:

- Hold the strap and pull it towards you.
- Hold onto the locking rail by the rubber grab handle and place the strap into the load bin.
- Gently pull the locking rail by the rubber grab handle towards the tailgate till you hear the latch engage.

MAINTENANCE & CLEANING:

For optimal performance of your Securi-Lid, please follow these instructions carefully.

GENERAL CLEANING:

a) Do not use thinners, acetone, spirits, petrol or any other abrasive agents to clean your Securi-Lid.

b) Car cleaning soap is recommended. Do not use strong chemicals such as acidic cleaners as this will damage the material finish.

c) Use a soft, lint free cloth or you may clean with a high pressure cleaner. Do not spray under high impact or at close range.

d) Avoid using any abrasive cleaning tools as this will damage the material finish.

e) During cleaning, water may enter the vehicle due to the high volume of water flow.

SIDE RAILS:

a) Keep side rail sections clean of excess dirt and sand by using a rag to wipe the inner section.

b) Spray a silicone based lubricant onto the plastic wear strip for a smoother action.

c) If wear strip is worn, contact your nearest distributor for replacement.

DRAIN PIPES:

a) Check drain pipes are free of dirt and allow water to flow freely.

To clean follow this procedure:

- Loosen hose clamp on canister.
- Pull pipe off canister.
- Once removed; check that the canister drainage holes are clear of any leaves or built up dirt/debris.
- Use high pressure water to flush out the drain pipes and canister drainage holes.